

iBT60



QUICK BLUETOOTH CONNECTION GUIDE

BEFORE YOU START

Your Bluetooth device (cellphone, MP3 player, computer, etc.) must support the **A2DP** Bluetooth profile (commonly known as stereo audio profile) to work with the iHome iBT60.

Many of the latest mobile phones and PCs with built-in Bluetooth functionality will support this profile. For accurate information about your product, please refer to your Bluetooth device's user manual for details on the Bluetooth profiles it supports and on how to set the device's Bluetooth pairing/searching/setup mode.



ABOUT PAIRING

Pairing is the term used when wirelessly connecting two Bluetooth devices for the first time.

This allows the devices to "see" each other and creates a unique lasting connection between the specific devices.

PAIRING & LINKING YOUR BLUETOOTH DEVICE WITH THE iBT60

- 1) Make sure your Bluetooth device is fully charged. Turn it on.
- 2) Turn on Bluetooth functionality on your Bluetooth device. Typically, Bluetooth controls are found on the device's tools or settings menu (see your user manual). Turn on Bluetooth connectivity and make your device "discoverable".
- 3) Slide the Bluetooth/On/Off Switch on the speaker to the Bluetooth position (⌘). The unit will turn on and attempt to auto link to a previously paired device for 10 seconds, indicated by a 3 note tone and the Indicator Light on the unit flashing blue. If a linked device is found, the indicator will glow solid blue.
- 4) If no linked device is found, the unit will enter pairing mode, indicated by a 2 note tone and the Indicator Light on the unit will flash blue and red while the unit attempts to pair. "iHome iBT60" should appear on your device's menu. If "Not Paired" or "Not Connected" or similar message appears, tap on the "iHome iBT60" to begin pairing. If your device asks for a password, enter 1234 on the keyboard of your device. If no device is paired within 2 minutes, a tone will sound and the unit will revert to auto link mode. To retry pairing, move the Bluetooth/On/Off Switch to the OFF position (O) then move it back to the Bluetooth position (⌘).
- 5) Once paired with a device, the Indicator Light on the unit will glow blue steadily. There should be an indication on your device that pairing is complete. On some devices, you must then select "Use as Audio Device" or similar on the device's Bluetooth menu. Once paired, your device should link to the iBT60 whenever within range.
- 6) Pairing remains intact when the iBT60 and/or the Bluetooth device is powered off or is taken out of link range (30 feet). The iBT60 supports auto-linking and will automatically re-establish an active connection when your Bluetooth device returns within range.
- 7) The next time the iBT60 is powered on it will automatically try to re-establish a link with the most recently linked Bluetooth device. If your device does not support auto-linking OR was not the last linked to the iBT60, you must re-link manually by selecting iBT60 from the Bluetooth device's menu on your Bluetooth device.
- 8) When you power ON the speaker, it will automatically link with the previously paired Bluetooth device as long as that device is still within range (about 30 feet). So, to pair with a different device you must turn off the Bluetooth capability of the already paired device.



GUIDE DE CONNEXION BLUETOOTH RAPIDE

AVANT DE COMMENCER

Pour fonctionner avec iHome iBT60 votre appareil Bluetooth (téléphone portable, lecteur MP3, ordinateur, etc.) doit supporter le profil Bluetooth A2DP (communément appelé profil audio stéréo).

La plupart des derniers modèles de téléphones portables et ordinateurs munis de fonctionnalité Bluetooth intégrée prendront en charge ce profil. Pour une information précise, veuillez vous référer au manuel de l'utilisateur de votre appareil Bluetooth pour des détails sur les profils Bluetooth qu'il prend en charge et comment définir les modes de couplage/recherche/connexion.

À PROPOS DU COUPLAGE

Le couplage est le terme utilisé lors de la première connexion sans fil de deux appareils Bluetooth.


Cela permet aux appareils de se « rencontrer » et de créer une connexion unique et durable entre les deux appareils spécifiques.

COUPLER ET CONNECTER VOTRE APPAREIL BLUETOOTH AVEC iBT60

- 1) Assurez-vous que votre appareil Bluetooth est complètement chargé. Allumez-le.
- 2) Activez la fonctionnalité Bluetooth de votre appareil Bluetooth. Typiquement, les contrôles Bluetooth se trouvent dans le menu d'outils ou de paramètres de l'appareil (voir votre manuel de l'utilisateur). Activez la connectivité Bluetooth et rendez votre appareil « visible ».
- 3) Positionnez le commutateur Bluetooth/On/Off/ de l'enceinte principale sur Bluetooth (*). L'unité s'allume et tente pendant 10 secondes d'établir automatiquement une connexion avec l'appareil précédemment couplé, signalée par le voyant qui clignote en bleu et l'émission de 3 bips. Le voyant devient bleu fixe si la connexion est réussie.
- 4) Si aucun appareil couplé n'est trouvé, l'unité passe en mode couplage, signalé par le voyant qui clignote en bleu et rouge et l'émission de 2 bips pendant les tentatives de couplage. « iHome iBT60 » doit apparaître dans le menu de votre appareil. Si « Not Paired », « Not Connected » ou un message similaire apparaît, sélectionnez « iHome iBT60 » pour terminer le couplage. Si votre appareil vous demande un mot de passe, entrez 1234 au clavier. Si aucun appareil n'est couplé pendant les 2 minutes suivantes, un signal sonore sera émis pour indiquer que l'unité retourne au mode de connexion automatique. Pour réessayer le couplage, positionnez le commutateur Bluetooth/On/Off sur OFF (O) puis le remettre sur Bluetooth (*).
- 5) Une fois couplée avec un appareil, le voyant de l'appareil s'allume en bleu fixe. Il doit y avoir un message sur votre appareil indiquant que le couplage est terminé. Sur certains appareils, vous devez sélectionner « Use as Audio Device » ou quelque chose de ce genre dans le menu Bluetooth de l'appareil. Une fois couplé, votre appareil devrait se connecter à iBT60 chaque fois qu'il se trouve à sa portée.
- 6) Le couplage reste intact lorsque l'iBT60 et/ou l'appareil Bluetooth est éteint ou emmené hors de portée (9.14 m). iBT60 supporte la connexion automatique et rétablira automatiquement une connexion active lorsque vos dispositifs Bluetooth seront de nouveau à portée.
- 7) La prochaine fois que l'iBT60 sera allumé, il essaiera automatiquement de rétablir une connexion avec l'appareil Bluetooth couplé le plus récemment. Si votre dispositif ne supporte pas la connexion automatique ou n'a pas été dernièrement connecté à iBT60, vous devez le reconnecter manuellement en sélectionnant iBT60 dans le menu de votre dispositif Bluetooth.
- 8) Lorsque vous allumez l'enceinte, elle se connecte automatiquement à l'appareil Bluetooth précédemment connecté tant que cet appareil est à portée (environ 9.14 m). Ainsi, pour coupler un autre appareil, vous devez désactiver le Bluetooth de l'appareil déjà connecté.



2



3