

iHome

Model: iWW33

TIME SET

- Press & Hold to Set Clock
- Use +/- to select 12/24 hour mode and press time set to confirm
- Use +/- to set the hour and press time set to confirm. PM Indicator will display for PM time. (There is no AM Indicator)
- Use +/- to set the minute and press time set to confirm

ALARM SET

- Press to Arm/Disarm Alarm
- Press & Hold to Set Alarm time
- Use +/- to set hour and press alarm to confirm
- Use +/- to set minute and press alarm to confirm
- Use +/- to set schedule (7 days, weekdays, weekends) and press alarm to confirm (alarm is 7 days until a date is set; See Date Set below)
- When alarm sounds, press alarm to disable and reset for the next day

SET

- Press to increase/decrease settings

SNOOZE/DIMMER

- Press to Snooze Alarm
- Press & Hold to Adjust Snooze Duration (adjust 1-29 min with +/- and press Snooze to confirm)
- Press and release to dim display: Aut1, Aut2, Aut0, Hi, 3, 2, Lo, and OFF

DATE SET/DST (DAYLIGHT SAVINGS)

- Press & Hold to Set Date
- Use +/- to select year and press date set to confirm
- Use +/- to set the month and press date set to confirm
- Use +/- to set the day and press date set to confirm
- Short press will show DST status on display.
- Short press toggles Auto/OFF

Battery Backup Compartment*

*When Low Backup Battery icon appears on the display, install two new AAA batteries

If use USB-A for charging, move the "SLIDE DOOR" to right side
If use USB-C for charging, move the "SLIDE DOOR" to Left side.

WIRELESS CHARGING

- Wireless charging devices (works with plastic cases up to 3mm thick)
- AirPods with wireless charging case

Place wireless charging device face up on the charging pad. LED Status Indicators will show charging status:

- Rapid blinking LED: Device is not charging (reposition device)
- Solid Amber LED: Device is charging
- LED OFF: Device is fully charged

For questions and additional information, please visit:
support.ihomeaudio.com/support/

WIRELESS POWERBOOST
4-in-1 MAGNETIC CHARGING CLOCK

PM Indicator — P 1008 — Alarm Indicator
— Low Backup Battery Indicator

LIGHT SENSOR
display will auto-dim to match light environment

SNOOZE DIMMER

alarm

time

alarm

time

alarm

time

alarm

time

alarm

time

alarm

time

alarm

time

alarm

time

alarm

time

alarm

time

alarm

time

alarm

time

alarm

time

alarm

time

alarm

time

alarm

time

alarm

time

alarm

time

alarm

time

alarm

time

alarm

time

alarm

time

alarm

time

alarm

time

alarm

time

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY

TOP OF DISPLAY