

iHome


STUDIO SERIES

FEATURING BONGIOVI ACOUSTICS DPS

USER GUIDE


W E L C O M E

Thank you for choosing the iHome Studio Series featuring Bongiovi Acoustics DPS. This user guide will get you up and running quickly and provide helpful hints to maximize enjoyment. For more information about this and other iHome products, please visit www.ihomeaudio.com



GETTING STARTED

Place unit on a stable surface. Plug the power adaptor into the adaptor jack on back of the unit and the other end into a wall socket.




Aux line-in for plugging in other audio devices.
For details, see page 5.

Component video jacks for displaying videos on your iPod/iPhone/iPad to TV (cord not included)
For details, see page 6.

Adaptor jack for powering unit.

MAIN CONTROLS



BONGIOVI DPS


The iHome Studio Series featuring Bongiovi Acoustics DPS (Digital Power Station) represents a genuine breakthrough in audio processing. This unique and powerful processor, years in the making, was developed by a team of audio engineers who have over 40 years of experience in the music and motion picture recording industries. Audio is digitally restored in real time, adding missing harmonics, improving clarity, presence, and bass resonance. Your music comes alive in ways never before possible.

i P A D , i P H O N E & i P O D


Docking & Charging your iPad, iPhone or iPod

Make sure your iPad/iPhone/iPod's firmware is up to date via iTunes before use. If your iPod/iPhone/iPad is in a thick case or skin, remove the rubber dock collar before docking. If you do not use a case or skin on your iPod/iPhone/iPad, you can adhere the rubber dock collar to the unit with the included adhesive tape for added stability when docking. Carefully dock your iPad/iPhone/iPod onto the dock. Your iPad, iPhone or iPod will charge while docked.

Remove rubber collar to dock an iPad, iPhone or iPod in a thick case



Leave rubber collar to dock an iPad, iPhone or iPod with no case



Listening to iPad, iPhone or iPod

Press the **Power Button** (or any button) to turn the unit on. Press Play on iPad/iPhone/iPod to listen to music. Adjust levels with **-** or **+** **Buttons**. Press the **DPS Button** to activate Bongiovi audio. When you are done listening, press the **Power Button** to turn the unit off. When unit is off, docking an already playing iPad/iPhone/iPod will turn it on.

U S I N G A U X L I N E - I N


AUX LINE-IN JACK

Connect one end of a standard stereo 3.5mm audio cable (not included) into the aux line-in jack on the back of your iHome and the other into the headphone or output jack of your audio device. Turn the device on and press play. Press the **Power Button** on the unit to turn it on. Adjust volume on your audio device and the unit as needed. Do not play a line-in audio device and a docked iPad/iPhone/iPod at the same time or you will hear both sources.


VIDEO - OUT

Your iHome is capable of outputting video stored on your iPad/iPhone/iPod to your television via the jacks on the rear. Depending on your model of iPad/iPhone/iPod, the supported video-out characteristics vary. See below.

For **component** video,
use the three jacks on rear



For **composite** video,
use only the center jack



iPod classic, iPod nano 1st-6th gen, iPod touch 1st-4th gen, iPhone 3GS, iPhone 4G, iPad: These iPod models can output progressive scan component video.

1G iPod touch, iPhone, iPhone 3G, iPhone 4G, iPad: These models can output interlaced component video.

All iPad/iPhone/iPod models also output composite video. To switch to composite video, turn your iHome on, hold Bongiovi DPS button (on front) and press the volume down (-) button. To switch back to component video, hold the Bongiovi DPS button and press the volume up (+) button. These steps will be necessary each time you dock your iPad/iPhone/iPod.

5G iPod: Only composite video is supported.

TROUBLESHOOTING

Symptom	Possible reason	Solution
Unit won't turn on	AC adaptor isn't plugged into a working wall socket or not plugged into the power jack on back of the unit	Plug the AC adaptor into a working wall socket and plug the connector into the supply jack on the unit
Unit won't respond	Unit may require a reset	If unit is plugged in and doesn't respond, try resetting the unit by following these steps: a) remove iPad/iPhone/iPod from dock b) unplug unit from power source c) wait 3 minutes, then resume use
	iPad/iPhone/iPod is not docked properly/dock is obstructed	Remove your iPad/iPhone/iPod from the dock and check for obstruction on the connectors in the dock and on your iPhone/iPod/iPad. Then reseat it in the dock.
iPad/iPhone/iPod does not respond to the unit and/or iPad/iPhone/iPod is playing but no sound comes out	iPad/iPhone/iPod is not docked properly	
	Your iPad/iPhone/iPod software is too old	Upgrade software on your iPad/iPhone/iPod via iTunes on your computer
	iPad/iPhone/iPod is locked up or plays but no sound comes out	Check the volume setting. Make sure your iPad/iPhone/iPod is working properly before docking into the unit. Please refer to your iPad/iPhone/iPod manual for details. See above for software upgrade information. You may need to reset your iPad/iPhone/iPod. Refer to your iPad, iPhone or iPod user guide for details on how to perform a reset.

TROUBLESHOOTING

Symptom	Possible reason	Solution
Erratic performance	External interference	Move unit away from potential sources of external interference such as computers, modems, wireless devices (routers) or fluorescent light.
No sound	Volume is too low	Turn volume up
Sound distorted	Volume is too high	Turn volume down
	Sound source is distorted	If the iPhone/iPod original sound file (MP3) is old or of poor quality, distortion and noise are easily noticed with high-power speakers. Try upgrading file from a trusted source such as iTunes.
	Bongiovi DPS and/or eq settings are set too high	Turn Bongiovi DPS off if necessary.
iPad/iPhone/iPod doesn't charge up	iPad/iPhone/iPod is locked up/ frozen	Please make sure your iPad/iPhone/iPod is working properly before docking into the unit. Please refer to your iPad/iPhone/iPod manual for details.
	iPad/iPhone/iPod battery has problem	
	iPad/iPhone/iPod is not docked properly	Remove your iPad/iPhone/iPod from the dock and check for obstruction on the connectors in the dock and on your iPad/iPhone/iPod.

IMPORTANT SAFETY TIPS

When used in the directed manner, this unit has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire hazards. Please read all safety and operating instructions carefully before installation and use, and keep these instructions handy for future reference. Take special note of all warnings listed in these instructions and on the unit.

1. Water and Moisture – The unit should not be used near water. For example: near a bathtub, washbowl, kitchen sink, laundry tub, swimming pool or in a wet basement.
2. Ventilation – The unit should be situated so that its location or position does not interfere with its proper ventilation. For example, it should not be situated on a bed, sofa, rug or similar surface that may block ventilation openings. Also, it should not be placed in a built-in installation, such as a bookcase or cabinet, which may impede the flow of air through the ventilation openings.
3. Heat – The unit should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat.
4. Power Sources – The unit should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.
5. Power-Cable Protection – Power supply cables should be routed so that they are not likely to be walked on or pinched by items placed upon or against them. It is always best to have a clear area from where the cable exits the unit to where it is plugged into an AC socket.
6. Cleaning – The unit should be cleaned only as recommended. See the Maintenance section of this manual for cleaning instructions.
7. Objects and Liquid Entry – Care should be taken so that objects do not fall and liquids are not spilled into any openings or vents located on the product.
8. Attachments – Do not use attachments not recommended by the product manufacturer.
9. Lightning and Power Surge Protection – Unplug the unit from the wall socket and disconnect the antenna or cable system during a lightning storm or when it is left unattended and unused for long periods of time. This will prevent damage to the product due to lightning and power-line surges.
10. Overloading – Do not overload wall sockets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
11. Damage Requiring Service – The unit should be serviced by qualified service personnel when:
 - A. the power supply cable or plug has been damaged.
 - B. objects have fallen into or liquid has been spilled into the enclosure.
 - C. the unit has been exposed to rain.
 - D. the unit has been dropped or the enclosure damaged.
 - E. the unit exhibits a marked change in performance or does not operate normally.
12. Periods of Non use – If the unit is to be left unused for an extended period of time, such as a month or longer, the power cable should be unplugged from the unit to prevent damage or corrosion.
13. Servicing – The user should not attempt to service the unit beyond those methods described in the user's operating instructions. Service methods not covered in the operating instructions should be referred to qualified service personnel.
14. Magnetic Interference: This product's speakers contain powerful magnets which could cause interference or damage to sensitive equipment such as hard drives, CRT televisions and monitors, as well as medical, scientific, and navigational devices. Keep this unit away from these products at all times.

Questions? Visit www.ihomeaudio.com

FCC INFORMATION

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


This equipment complies with the limits for a Class B digital device as specified in Part 15 of FCC Rules. These limits provide reasonable protection against radio and TV interference in a residential area.

However, your equipment might cause TV or radio interference even when it is operating properly. To eliminate interference you can try one or more of the following corrective measures:

- Reorient or relocate the receiving antenna.
 - Increase the distance between the equipment and the radio or TV.
 - Use outlets on different electrical circuits for the equipment and the radio or TV.
 - Consult your dealer or an experienced radio/television technician if the problem still exists.
- Modifying or tampering with your system's internal components can cause a malfunction and might invalidate the system's warranty and void your FCC authorization to operate it.

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.



LIMITED 1 YEAR WARRANTY

iHome Products, a division of SDI Technologies Inc. (hereafter referred to as SDI Technologies), warrants this product to be free from defects in workmanship and materials, under normal use and conditions, for a period of 1 Year from the date of original purchase.

Should this product fail to function in a satisfactory manner, it is best to first return it to the store where it was originally purchased. Should this fail to resolve the matter and service still be required by reason of any defect or malfunction during the warranty period, SDI Technologies will repair or, at its discretion, replace this product without charge (except for a \$30.00 charge for handling, packing, return UPS/postage, and insurance). This decision is subject to verification of the defect or malfunction upon delivery of this product to the Factory Service Center listed below. The product must include proof of purchase, including date of purchase. The fee for service without proof of purchase is \$90.00. Before returning this product for service, please first replace the batteries (if applicable) with fresh ones, as exhausted or defective batteries are the most common cause of problems encountered.

If service is still required:

1. Remove the batteries (if applicable) and pack the unit in a well padded, heavy corrugated box.
2. Enclose a photocopy of your sales receipt, credit card statement, or other proof of the date of purchase, if within the warranty period.
3. Enclose a check or money order payable to the order of SDI Technologies, for the sum of \$30.00 (\$90.00 without proof of purchase).
4. Send the unit prepaid and insured, to the Factory Service Center listed below.

**Consumer Repair Department
SDI Technologies Inc.
1330 Goodyear Dr.
El Paso, TX 79936-6420**

Disclaimer of Warranty

NOTE: This warranty is valid only if the product is used for the purpose for which it was designed. It does not cover (i) products which have been damaged by negligence or willful actions, misuse or accident, or which have been modified or repaired by unauthorized persons; (ii) cracked or broken cabinets, or units damaged by excessive heat; (iii) damage to digital media players, CD's or tape cassettes (if applicable);

(iv) the cost of shipping this product to the Factory Service Center and its return to the owner.

This warranty is valid only in the United States of America and does not extend to owners of the product other than to the original purchaser. In no event will SDI Technologies or any of its affiliates, contractors, resellers, their officers, directors, shareholders, members or agents be liable to you or any third party for any consequential or incidental damages, any lost profits, actual, exemplary or punitive damages. (Some states do not allow limitations on implied warranties or exclusion of consequential damages, so these restrictions may not apply to you.) This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Your acknowledgment and agreement to fully and completely abide by the above mentioned disclaimer of warranty is contractually binding to you upon your transfer of currency (money order, cashier's check, or credit card) for purchase of your SDI Technologies product.

Questions? Visit www.ihomeaudio.com Toll Free Customer Service: 1-877-446-6301