Model: iF100
Instruction manual - US English
Date: Jan 10, 2019

iHome

iHome | AIR

FAN + SOUND MACHINE

Model: iF100
Personal Air Circulator with Built-in Sound Machine

QUESTIONS? visit www.ihome.com or call 1-800-288-2792


WELCOME

Thank you for choosing the iF100 2-in-1 Personal Air Circulator with Built-in Sound Machine from iHome. For more information about this and other iHome products, please visit **www.ihome.com**

GETTING STARTED

This unit ships with the following items. Please check to see that all items are present.
1. iF100 Fan
2. AC adapter

1. iF100 Fan   2. AC adapter

MAINTENANCE

- Place the unit on a level surface away from sources of direct sunlight or excessive heat.
- Protect your furniture when placing your unit on a natural wood and lacquered finish. A cloth or other protective material should be placed between it and the furniture.
- **WARNING:** Prior to cleaning, always turn OFF the power and unplug the product from the outlet.
- This product has no serviceable parts inside and cannot be opened for cleaning - Never clean in any manner other than instructed in this manual.
- Clean/dust the product with a soft cloth, slightly moistened only with mild soap and water, as stronger cleaning agents can damage the surface of the unit. (Alternative method: Use the brush attachment on your household vacuum cleaner to vacuum accumulated dust or debris.)
- Clean your product regularly and only as instructed in this manual.

1

FEATURES & FUNCTIONS

BUTTON PANEL

FAN TIMER LED   SOUND TIMER LED

FAN SPEED   FAN TIMER   VOLUME DOWN   POWER   VOLUME UP   SOUND TIMER   SOUND THERAPY

BOTTOM PANEL

Connect the included AC adapter into the DC jack on the bottom of the unit, and connect the plug to a working outlet not controlled by a light switch.

2

USING THE FAN

Press the **POWER** button to turn the fan ON or OFF.

Press the **Fan Button** to cycle through three different fan modes: Low, High, and OFF.

FAN TIMER

Press the Fan Timer Button to set the duration of the timer. A voice prompt will call out each selection (10 minutes, 30 minutes, 1 hour, 2 hours, 4 hours, 6 hours, 8 hours, or OFF).

Once the timer is set, the LED above the Fan Timer Button will indicate the amount of time counting down:

Green: >60 minutes of fan time remaining
Yellow: 11-59 minutes of fan time remaining
Red: 10 minutes or less of fan time remaining

- Press the Fan Button to change fan speeds at any time.
- *Press and hold* the Fan Timer Button to turn the timer OFF.
- *Press and hold* the Fan Button to power the fan OFF.

3

SOUND THERAPY

Press the **Sound Therapy Button** to access Sound Therapy mode. Continue to press to cycle to each mode:

- Air (Brown Noise)
- Focus (Pink Noise)
- Quiet (White Noise)
- Peace (White Noise + Tones)
- Drive
- Calming Meditation
- Zen
- Dream Tones
- Ocean
- Storm
- Nature
- River
- OFF

Sound Therapy is designed to help create a sound barrier to reduce background noise, promoting sleep and relaxation.

SOUND THERAPY TIMER

Press the Sound Timer Button to set the duration of the timer. A voice prompt will call out each selection (10 minutes, 30 minutes, 1 hour, 2 hours, 4 hours, 6 hours, 8 hours, or OFF).

Once the timer is set, the LED above the Sound Timer Button will indicate the amount of time counting down:

Green: >60 minutes of audio remaining
Yellow: 11-59 minutes of audio remaining
Red: 10 minutes or less of audio remaining

- Press the Sound Therapy Button to change audio tones at any time.
- *Press and hold* the Sound Timer Button to turn the timer OFF.
- *Press and hold* the Sound Therapy Button to turn off tones.

4

SMARTPLUG POWER PRESET

The SmartPlug Power Preset is an advanced function designed for people who utilize smart plugs in their home. Use this function to power on the iF100 directly from the AC adapter, without pressing the Power Button. (Preset is inactive by default).

To set up your Power Preset preferences:
- Adjust the fan speed, sound mode, and volume to your desired levels.
- *Press and hold* the Power button for 5 seconds to save your preset.
- A voice prompt will confirm when your custom preset is saved.

To de-activate your Power Preset preferences:
- *Press and hold* the Power button for 5 seconds.

Using the iF100 with Smart Plugs:
- When a preset is saved and the iF100 is connected to a smart plug, you can program a custom default state for when AC power is activated. (For example, you can set the default state to Fan Speed High + Zen Sounds any time a connected smart plug is activated or when the unit plugged directly into an AC outlet).

- When connected to compatible smart plugs, the iF100 can be turned ON/OFF remotely via voice commands to Siri, Google, or Alexa.

- You can also set a Power ON/OFF schedule to activate at a specific time or day (consult your preferred smart plug brand and product manual for details).

5

IMPORTANT SAFETY INSTRUCTIONS

When used in the directed manner this product has been designed and manufactured to ensure your personal safety. However, improper use can result in potential electrical shock or fire hazard. Please read all safety and operating instructions carefully before installation and use. Keep these instructions handy for future reference. Take special note and heed all Warnings listed.

1. Heat – The unit should be situated away from heat sources such as radiators, heat registers, stoves or other appliances (including amplifiers) that produce heat.
2. Only use attachments/accessories specified by the manufacturer. Only use the AC adapter that came with the unit.
3. This product is suitable for use in warm and/or moderate climates.
4. No naked flame sources, such as lighted candles, should be placed on or near the apparatus.
5. Cleaning - The unit should be cleaned only as recommended. See the Maintenance section of this manual for cleaning instructions.
6. Unplug this product during lightning storms or when unused for long periods of time.
7. WARNING: To reduce the risk of fire or electric shock, do not expose this product to weather or the elements. For indoor use only.
8. WARNING: DO NOT place this product near curtains, draperies or other fabric that could be drawn into the product and damage the motor and/or cause a fire. The unit should be situated so that its location or position does not interfere with its proper ventilation.
9. The mains plug of power adaptor is used as the disconnect device, it shall remain readily operable.
10. The product should be placed near an easily accessible outlet so that the unit can be unplugged during an emergency.
11. Damage Requiring Service – The unit should be serviced by qualified service personnel when:
- the power supply cable or plug has been damaged.
- objects have fallen into or liquid has been spilled into the enclosure.
- the unit has been exposed to rain.
- the unit has been dropped or the enclosure damaged.
- the unit exhibits a marked change in performance or does not operate normally.
12. Supervision is required during set-up, operation, cleaning and maintenance of this product by children under 14 and anyone with reduced sensory, physical or mental capabilities to ensure that they do not play with the product during use.
13. Water and Moisture – DO NOT use this product in a bathtub, shower or position where it can fall into a bathtub, sink, laundry, pool or hot tub.
14. Objects and Liquid Entry – Care should be taken so that objects do not fall and liquids are not spilled into any openings or vents located on the product.
15. DO NOT run cord under furniture, appliances, and carpeting or cover cord with throw rugs, runners or other similar coverings.
16. Magnetic Interference: This product's speakers contain powerful magnets which could cause interference or damage to sensitive equipment such as hard drives, CRT televisions and monitors, as well as medical, scientific, and navigational devices. Keep this unit away from these products at all times.
17. THIS IS NOT A TOY.

6

FCC INFORMATION

WARRANTY

For product support information and warranty please visit:
www.ihome.com/support

iF100-190108-A(EN)   Printed in China